



THIS DEVICE IS FM APPROVED

The pressure vs. flow rate data developed within this flow chart is based on the average K-factor measured during laboratory testing. This data has been determined to be within the acceptable limitations for accuracy. It is the user's responsibility to verify that the correct chart and column are being used.

HM2H | 2½" Hose Monster Model II or Flusher with flow splitter (HM2H, HM2HF)

Use this column if the Pitotless Nozzle is connected to the 2½" Hose Monster or Flusher. The built-in pitot or flow splitter must be installed for accuracy.

OA | Open Atmosphere Use this column when the Pitotless Nozzle is connected directly to a test header or hydrant flowing openly to atmosphere.

GET THE MOST OUT OF YOUR HOSE MONSTER™ HARDWARE

FIRE PUMP TESTING SOFTWARE

Professional-grade software that helps you work better! Keep your reports clean, your results accurate, and your process streamlined with Hose Monster's FPT Software.

LEARN MORE AT [HOSEMONSTER.COM/RESOURCES](https://www.hosemonster.com/resources)

1½" PITOTLESS NOZZLE™

PN1.125THD-LPM FLOW CHART

LPMFC-PN1125THD.2021.09.21.MA

	HM2H	OA		HM2H	OA		HM2H	OA
PSI	LPM	LPM	PSI	LPM	LPM	PSI	LPM	LPM
5	317	313	33	813	804	61	1106	1094
6	347	343	34	825	817	62	1115	1103
7	375	371	35	837	829	63	1124	1112
8	400	396	36	849	840	64	1132	1120
9	425	420	37	861	852	65	1141	1129
10	448	443	38	873	863	66	1150	1138
11	469	464	39	884	875	67	1159	1146
12	490	485	40	895	886	68	1167	1155
13	510	505	41	906	897	69	1176	1163
14	530	524	42	917	908	70	1184	1172
15	548	542	43	928	918	71	1193	1180
16	566	560	44	939	929	72	1201	1188
17	584	577	45	950	939	73	1209	1197
18	601	594	46	960	950	74	1218	1205
19	617	610	47	970	960	75	1226	1213
20	633	626	48	981	970	76	1234	1221
21	649	642	49	991	980	77	1242	1229
22	664	657	50	1001	990	78	1250	1237
23	679	672	51	1011	1000	79	1258	1245
24	693	686	52	1021	1010	80	1266	1253
25	708	700	53	1031	1020	MANUFACTURED BY THE HOSE MONSTER™ COMPANY		
26	722	714	54	1040	1029			
27	736	728	55	1050	1039			
28	749	741	56	1059	1048			
29	762	754	57	1069	1057			
30	775	767	58	1078	1067			
31	788	780	59	1087	1076			
32	801	792	60	1097	1085			

PITOTLESS NOZZLE™

THREADED INSTRUCTIONS

The Pitotless Nozzle™ Threaded (PN#THD) must be used in conjunction with the 2½" Hose Monster Model II (HM2H, HM2HF) or attached directly to a hydrant or test header valve discharging into open atmosphere.

Note: If you intend to use the Pitotless Nozzle with the Little Hose Monster (HML), then a Pitotless Nozzle Grooved (PN#GRV) is required. Do not use the Pitotless Nozzle Threaded (PN#THD) with the Little Hose Monster. Call us if you are considering a configuration not listed here.

PITOTLESS NOZZLE™ SETUP

The gauge connection on the Pitotless Nozzle™ is a factory-installed male end of a quick-disconnect coupling. One female counterpart is included, and additional ones can be purchased separately. Attach the female end of the quick-disconnect coupling directly to the gauge or remote reader adapter, and use the quick-disconnect feature to attach and remove. Do not remove the male quick-disconnect from the Pitotless Nozzle, as it will damage the threads on the Pitotless Nozzle.

We recommend a gauge with an accuracy rating of 0.5% or better and of a suitable range.


PITOTLESS NOZZLE™ USE

WITH THE MODEL II, 2½" HOSE MONSTER™ OR FLUSHER

Insert the male outlet of the Pitotless Nozzle into the swivel coupling of the Hose Monster. Hand-tighten plus about a quarter-turn using a rocker lug spanner wrench on the swivel coupling and a pin lug spanner wrench (WSPA104) for a holdback on the Pitotless Nozzle. Attach the male end of a hose into the swivel coupling on the Pitotless Nozzle. Hand-tighten plus about a quarter-turn using spanner wrenches. The pitot/flow splitter must remain on either unit in order to collect accurate flow rates. Make sure the hose lies flat and is not twisted.

ON A HYDRANT OR TEST HEADER VALVE

The Pitotless Nozzle must be attached securely to a pump test header valve or hydrant. Secure the female swivel coupling of the Pitotless Nozzle directly to a hydrant nozzle or test header valve. The Pitotless Nozzle points in the direction the water will flow. Clear water discharge path.



WARNING

- **Do not** attach the Pitotless Nozzle™ to the end of a hose unless the Hose Monster is attached or it is **permanently** secured.
- **Do not** attach a hose to the male outlet end of the Pitotless Nozzle™ **under any circumstance**. The backpressure will distort flow rate reading.
- **Do not** remove the gauge port quick-disconnect fitting. The aluminum threads **will be damaged**. Contact Hose Monster™ for any repairs.

LHM			OA		
PSI	GPM	GPM	PSI	GPM	GPM
10	533	282	41	1080	570
11	559	295	42	1093	577
12	584	308	43	1106	584
13	608	321	44	1119	591
14	631	333	45	1131	597
15	653	345	46	1144	604
16	675	356	47	1156	610
17	695	367	48	1169	617
18	716	378	49	1181	623
19	735	388	50	1193	630
20	754	398	51	1205	636
21	773	408	52	1216	642
22	791	418	53	1228	648
23	809	427	54	1239	654
24	826	436	55	1251	660
25	843	445	56	1262	666

FLOW CHARTS

Pitotless Nozzle™ flow charts must be used to determine discharge flow rate. The use of flow charts of a different device or size will result in incorrect readings. Within the flow chart is a column for “Little Hose Monster” and for “Open Atmosphere.” Use the “Little Hose Monster” flows if the Pitotless Nozzle™ is attached to a Little Hose Monster. Use the “Open Atmosphere” flows if the Pitotless Nozzle™ is attached directly to a hydrant or test header valve discharging out into the open.

Flow charts are provided with the Pitotless Nozzle, and additional copies are available on our website at www.hosemonster.com



Find this as well as other product guides at www.hosemonster.com/resources