

THIS DEVICE IS FM APPROVED

The pressure vs. flow rate data developed within this flow chart is based on the average K-factor measured during laboratory testing. This data has been determined to be within the acceptable limitations for accuracy.

It is the user's responsibility to verify that the correct chart and column is being used.

HML | Little Hose Monster™ - Use this column when the Pitotless Nozzle is connected to a Little Hose Monster.

OA | Open Atmosphere - Use this column when the Pitotless Nozzle is connected directly to a test header or hydrant flowing openly to atmosphere.

Find this flow chart and other resources at:

hosemonster.com/resources

GET THE MOST OUT OF YOUR HOSE MONSTER™ HARDWARE

FIRE PUMP TESTING SOFTWARE

Professional-grade software that helps you work better! Keep your reports clean, your results accurate, and your process streamlined with Hose Monster's FPT Software.

Learn more at: www.hosemonster.com/fpts

1 1/8" PITOTLESS NOZZLE™

PN1.125GRV - LPM FLOW CHART

	HML	OA	
PSI	LPM	LPM	
5	315	313	
6	345	343	
7	373	371	
8	398	396	
9	422	420	
10	445	443	
11	467	464	
12	488	485	
13	508	505	
14	527	524	
15	545	542	
16	563	560	
17	581	577	
18	597	594	
19	614	610	
20	630	626	
21	645	642	
22	660	657	
23	675	672	
24	690	686	
25	704	700	
26	718	714	
27	732	728	
28	745	741	
29	758	754	
30	771	767	
31	784	780	
32	796	792	

	HML	OA	
PSI	LPM	LPM	
33	809	804	
34	821	817	
35	833	829	
36	845	840	
37	856	852	
38	868	863	
39	879	875	
40	891	886	
41	902	897	
42	913	908	
43	923	918	
44	934	929	
45	945	939	
46	955	950	
47	965	960	
48	976	970	
49	986	980	
50	996	990	
51	1006	1000	
52	1015	1010	
53	1025	1020	
54	1035	1029	
55	1044	1039	
56	1054	1048	
57	1063	1057	
58	1072	1067	
59	1082	1076	

1091

60

	HML	OA
PSI	LPM	LPM
61	1100	1094
62	1109	1103
63	1118	1112
64	1126	1120
65	1135	1129
66	1144	1138
67	1153	1146
68	1161	1155
69	1170	1163
70	1178	1172
71	1186	1180
72	1195	1188
73	1203	1197
74	1211	1205
75	1219	1213
76	1227	1221
77	1236	1229
78	1244	1237
79	1251	1245
80	1259	1253



PITOTLESS NOZZLE™

GROOVED INSTRUCTIONS


The Pitotless Nozzle™ Grooved (PN#GRV) must be used in conjunction with the Little Hose Monster™ (HML) or attached directly to a hydrant or test header valve, discharging into open atmosphere.

The flow chart has two columns entitled Little Hose Monster™ and Open Atmosphere. Be sure to use the appropriate column to determine flow rates. Contact Hose Monster™ if you are considering a configuration not listed here.

PITOTLESS NOZZLE™ SETUP

The gauge connection on the Pitotless Nozzle[™] is a factory-installed male end of a quick disconnect coupling. One female counterpart is included and additional ones can be purchased separately. Attach the female end of the quick disconnect coupling directly to the gauge or remote reader adapter and use the quick disconnect feature to attach and remove. Do not remove the male quick disconnect from the Pitotless Nozzle as it will damage the threads on the Pitotless Nozzle.

We recommend a gauge with an accuracy rating of ½% or better and of a suitable range.



PITOTLESS NOZZLE™ USE

WITH LITTLE HOSE MONSTER™

Line up the Pitotless Nozzle outlet at the inlet of the Little Hose Monster with the gauge port rotated to 45° off either side of vertical. Push the Nozzle all the way in until the latch lever arms hook into the groove. Rotate the Nozzle right or left until the latch levers snap parallel to the body and the gauge port is in the desired position. The gauge port can be positioned so that a gauge can be viewed in a vertical position, or horizontal to the left or right side of the Little Hose Monster. Insert the locking pins all the way through the pinhole and latch-lever arm. When the Pitotless Nozzle is installed, securely attach a hose using a spanner wrench. Make sure the hose lays flat and is not twisted.

ON A HYDRANT OR TEST HEADER VALVE

The Pitotless Nozzle must be attached securely to a pump test header valve or hydrant. Secure the female swivel coupling of the Pitotless Nozzle directly to a hydrant nozzle or test header valve. The Pitotless Nozzle points in the direction the water will flow. Clear water discharge path.

WARNING

- Do not attach the Pitotless Nozzle[™] to the end of a hose unless the Hose Monster is attached or it is permanently secured.
- Do not attach a hose to the male outlet end of the Pitotless Nozzle™ under any circumstance.
 The backpressure will distort flow rate reading.
- Do not remove the gauge port quick disconnect fitting. The aluminum threads will be damaged. Contact Hose Monster[™] for any repairs.

	LHM	OA			LHM	OA
	GPM	GPM	P:		GPM	GPM
10	533	282	4	1	1080	570
11	559	295	4.	2	1093	577
12	584	308	4	3	1106	584
13	608	321	4	4	1119	591
14	631	333	4	5	1131	597
15	653	345	4	6	1144	604
16	675	356	4	7	1156	610
17	695	367	4	3	1169	617
18	716	378	4	9	1181	623
19	735	388	5)	1193	630
20	754	398	5	1	1205	636
21	773	408	5	2	1216	642
22	791	418	5	3	1228	648
23	809	427	5-	4	1239	654
24	000	42.0		_	1051	000

FLOW CHARTS

Pitotless Nozzle[™] flow charts must be used to determine discharge flow rate. The use of flow charts of a different device or size will result in incorrect readings. Within the flow chart is a column for "Little Hose Monster" and for "Open Atmosphere". Use the "Little Hose Monster" flows if the Pitotless Nozzle[™] is attached to a Little Hose Monster. Use the "Open Atmosphere" flows if the Pitotless Nozzle[™] is attached directly on a hydrant or test header valve discharging out into the open.

Flow charts are provided with the Pitotless Nozzle and additional copies are available on our website at www.hosemonster.com

